




**TUNNELTON MINING COMPANY**  
**OVERVIEW MAP OF THE FINAL AIRFLOW**  
SCALE 1" = 1000'  
POSTED 1-1-94

 DEPICTS GENERAL AIRFLOW PATTERNS ONCE CONTROLS HAVE BEEN REMOVED.

**FINAL ABANDONMENT PROCEDURES**

The following will occur before any ventilation control devices are removed:

1. Mine power will be permanently disconnected.
2. Certified officials will be stationed at a mine phone in the inby areas where work is to proceed.
3. SCSR's will be carried by all personnel at all times during the final change.

After personnel are in place, the order to start the final changes will be given. Men will proceed outby making changes until all work shown on Maps 1-4 is completed. Once everyone is accounted for, the men will exit the mine at # 1 or # 2 shaft. After immediately after exiting, the procedures for barricades at the mine entrances, and electrically disabling the elevators will be carried out. (See MINE CLOSURE PLAN).

*Handwritten signature and date:*  
8-18-94