

Fit to 17

Fit to 19



NO MINING TO BE DONE IN THIS BARRIER UNTIL EITHER THE IMPOUNDED WATER HAS BEEN REMOVED OR ALL COAL BELOW THE IMPOUNDED WATER HAS EITHER BEEN MINED OR PERMANENTLY ABANDONED.

- Procedure for driving Hoffman Drain:
- 1- From B to A, 1 from B to C, drive 8 feet.
 - 2- Drive from C to D using three conveyors, B, C, and C to D.
 - 3- Drive 19 butt from A to find elev. 1725.25 at F, extend for full row.
 - 4- After repositioning from F to D and from F to H, drive between these points.

Note: Driving in the solid, not to exceed 15 feet wide (LHS).
 Survey for location and elevations to be made connecting points C and H, also points J and F, before any driving from point F.
 11-7-1946