


LEGEND

9762 — Mine Number (See Reference Card for Additional Information)

* 9762 — Asterisk Indicates Pre 1966 Permit or Certificate



9762 — Limits of Mining (See Card to Determine Deep or Surface Mine)



9762 — Limits of Mining (Permit or Certificate Refused)

— Deep Mine Location (Mine Maps Showing Extent of operation Not Available)


—* 9762 (Ref.) — Deep Mine Location (Permit or Certificate Refused)

○ — Borehole (Ref. following Number Indicates Refusal)

■ — Shaft (Ref. following Number Indicates Refusal)

----- Coal Seam Outcrop

△1820.3 — Bottom of Coal Elevations



SL 108 — Operation Scarlift Reclamation Project

NOTE: (N/S) or (No Seam) Indicates Name of Coal Seam Not Specified on Application