



Posting Plan
 Graff 1-2 Mine
 Mechanical Mining
 Scale 1" = 5'
 2-4-49.

CROSS BARS SET AT 36" CENTERS TO WITHIN 18" OF FACE (SHUTTLE CAR HAULAGE)

JOY OPERATOR SHALL NOT ADVANCE BEYOND 6' OF LAST CROSS BAR WITHOUT FIRST SETTING SAFETY POST.

NO PERSON, EXCEPT THOSE DULY AUTHORIZED, SHALL ENTER ANY WORKING PLACE WHILE MACHINERY IS IN MOTION UNLESS MACHINERY HAS FIRST BEEN BROUGHT TO A FULL AND COMPLETE STOP.