


BOUNDARY LINE  
EXCHANGE LINE  
5925-Y 01 LT  
5925-Y 02 LT  
5925-Y 03 LT  
5925-Y 04 LT  
5925-Y 05 LT  
5925-Y 06 LT  
5925-Y 07 LT  
5925-Y 08 LT  
5925-Y 09 LT  
5925-Y 10 LT  
5925-Y 11 LT  
5925-Y 12 LT  
5925-Y 13 LT  
5925-Y 14 LT  
5925-Y 15 LT  
5925-Y 16 LT  
5925-Y 17 LT  
5925-Y 18 LT  
5925-Y 19 LT  
5925-Y 20 LT  
5925-Y 21 LT  
5925-Y 22 LT  
5925-Y 23 LT  
5925-Y 24 LT  
5925-Y 25 LT  
5925-Y 26 LT  
5925-Y 27 LT  
5925-Y 28 LT  
5925-Y 29 LT  
5925-Y 30 LT

ARNOLD 2 MINE  
FIT TO K-5247  
FIT TO K-5245  
FIT TO K-5243  
ARNOLD 2 MINE  
FIT TO K-5244



MINED OUT  
MINED OUT  
MINED OUT

MINED OUT