



Arrows show direction of air currents with use of Automatic doors on haulage way & the hoist shaft the outlet.

JOSEPH H. REILLY COAL CO.

H 20167
1-5 21000
CO

JOHN LANTZY.

N 41 E

2022.0