

J O H N W H I T E M A N T R A C T

J O H N Y O U N G T R A C T

Mc Cartel

LEASE LINE

D A V I D S O N T R A C T

VENTILATION SYMBOLS			
⊙ = Main Fan	⊞ = Air Bridge	⊞ = Air Bridge	
⊙ = Auxiliary Fan	⊞ = Regulator	⊞ = Regulator	
⊞ = Air Flow - Intake	⊞ = Man Door	⊞ = Man Door	
⊞ = Air Flow - Exhaust	V = Velocity, fpm	V = Velocity, fpm	
⊞ = Permanent Stopping	Q = Quantity, cfm	Q = Quantity, cfm	
⊞ = Temporary Stopping	WG = Water Gauge	WG = Water Gauge	

MINE MAP
Showing the location and extent of development of the Keno Coal Co. slope mine, Situate on the S. dip Seven Foot Vn., Conyngham Township, Columbia County, Pa.
A.B. Riedel, P.E. Oct. 20, 1985
Scale 1"= 100'

A.B. Riedel