

GREAT ANTHRACITE COAL COMPANY

BOSLEGO

READING ANTHRACITE COMPANY

NORTHUMBERLAND
COUNTY COMMISSIONERS

LEONA BOSLEGO

ALEXANDER HUNTER WARRANTEE TRACT

LAND SALES COLLIERY

ROSINI COAL COMPANY

ROBERT DONAHUE

VENTILATION SYMBOLS

- ⊙ = Main Fan
- ⊙ = Auxiliary Fan
- = Air Flow - Intake
- ← = Air Flow - Exhaust
- ⊞ = Permanent Stopping
- ⊞ = Temporary Stopping
- ⊞ = Air Bridge
- R = Regulator
- M = Man Door
- V = Velocity, fpm
- Q = Quantity, cfm
- WG = Water Gauge
- ⊞ = Escapeway
- BEP = Bleeder Evaluation Point

MINE MAP
OF THE
OLAF COAL COMPANY, INC.
situate on the
North Dip 80 Vein
West Cameron Twp., Northumberland County
No. 1 Scale
36-0764
Scale 1 inch = 100 Feet
MAP POSTING FEBRUARY 22, 1992

Asa B. Lued