

NORTHUMBERLAND
COUNTY COMMISSIONERS

LEONA BOSLEGO

ALEXANDER HUNTER WARRANTEE TRACT


ROSINI COAL COMPANY

ROBERT DONAHUE



VENTILATION SYMBOLS	
	= Main Fan
	= Auxiliary Fan
	= Air Flow - Intake
	= Air Flow - Exhaust
	= Permanent Stopping
	= Temporary Stopping
	= Air Bridge
	= Regulator
	= Man Door
	= Velocity, fpm
	= Quantity, cfm
	= Water Gauge
	= Escapeway
	= Bleeder Evaluation Point

MINE MAP
of the
OLAF COAL COMPANY
situate on the
North Dip #0 Vein
West Cameron Twp., Northumberland County



Olaf A. Reed