
SCALE 1"=50'
CROSS SECTION 6+00
LOOKING EAST


SCALE 1"=50'
CROSS SECTION 8+00
LOOKING EAST


SCALE 1"=50'
CROSS SECTION 10+00
LOOKING EAST


SCALE 1"=50'
CROSS SECTION 12+00
LOOKING EAST

SCALE 1"=50'
CROSS SECTION 14+00
LOOKING EAST


SCALE 1"=50'
CROSS SECTION 16+00
LOOKING EAST


SCALE 1"=50'
CROSS SECTION 7+00
LOOKING EAST


SCALE 1"=50'
CROSS SECTION 9+00
LOOKING EAST


SCALE 1"=50'
CROSS SECTION 11+00
LOOKING EAST


SCALE 1"=50'
CROSS SECTION 13+00
LOOKING EAST


SCALE 1"=50'
CROSS SECTION 15+00
LOOKING EAST

SCALE 1"=50'
CROSS SECTION 17+00
LOOKING EAST


SCALE 1"=50'
CROSS SECTION 8+00
LOOKING EAST


SCALE 1"=50'
CROSS SECTION 10+00
LOOKING EAST


SCALE 1"=50'
CROSS SECTION 12+00
LOOKING EAST


SCALE 1"=50'
CROSS SECTION 14+00
LOOKING EAST


SCALE 1"=50'
CROSS SECTION 16+00
LOOKING EAST


SCALE 1"=50'
CROSS SECTION 18+00
LOOKING EAST